

Fitting Instructions 0121IS

GM Opel Kadett etc.
Steering Coupling Bushing

Rivet heads to be removed with 3/8 drill after marking with centre punch;
Use a 5/16 punch to drive out rivets
Using hardware supplied and all original washers, re-assemble as shown.

NOTE: Failsafe Collar must be retained.

